


INSERT LINE CORD  
IN SLOT



STD. 738



STD. 774

POWER

ON

STD. 739

VIEW SCREEN IN MIRROR WHILE  
← ADJUSTING MONITOR.

STD. 740

1. **DEPRESS ADVANCE PUSHBUTTON TO DISPLAY BOOKEEPING TOTALS ON SCREEN.**
2. **RECORD BOOKEEPING TOTALS.**
3. **DEPRESS ADVANCE PUSHBUTTON TWO TIMES TO RETURN TO GAME OVER.**

↗  
**ACCESS TO  
ADVANCE  
PUSHBUTTON  
(FOR BOOKEEPING  
TOTALS) THRU  
HOLE IN TOP OF  
COIN BOX HOUSING.**

STD. 734